# INTRODUCING The Immovator Drain

PVC

ABS

INSTALLED

POON Series
PVC

POON Series
ABS

900N Series
ABS

901N Series
ABS

901N Series
ABS



## Designer White Bathtub Drains!

- Quick, one-person installation; installs in minutes
- Integrated strainer body/drain elbow eliminates one solvent weld joint;
   fewer joints = fewer problems
- Standard high gloss, designer white
- Chrome and 12 other finishes available with QuickTrim® or Universal NuFit®
- Corrosion resistant strainer body, overflow plate and stopper
- Overflow and drain come standard with test membranes; testable up to five floors (22 psi)
- Available in ABS or PVC; Flex Series in PVC only. ABS drain elbow is white
- Removable/replaceable crossbars make drains easy to clean and maintain
- Available with rough-ins and trim (stopper, faceplates) packaged separately
- Five year limited warranty





## The Innovator Bathtub Drain Installs In Minutes!

- 1. From inside the tub, insert drain elbow through tub drain.
- 2. Position and align drain elbow. From under the tub, slip on rubber seal, slip washer and nut and tighten to tub.
- 3. Install foam overflow elbow washer up to the flange of the overflow elbow. Push overflow elbow through tub overflow opening.











- 4. From inside the tub, hand tighten the retainer star nut onto the overflow elbow.
- 5. After pressure testing, use knife to cut out test membranes from overflow and drain elbows.
- 6. Snap on overflow plate with overflow slot facing down.
- 7. Tighten the push pull® stopper pin into threaded crossbar. Thread on knob.

### 12 Additional Finishes Available With OuickTrim® Or Universal NuFit®







Universal NuFit®

For current pricing visit watcomfg.com For more information contact:

QuickTrim®

#### **Watco Manufacturing Company** Always A Step Ahead



1220 South Powell Road Independence, MO 64057-2724 tel 816.796.3900 fax 816.796.0875 watcomfg.com